



These acoustic hangers have been conceived for the suspension of false ceilings, vibrating pipelines and machinery that has to be suspended.

The excellent properties of the Sylomer® microcellular polyurethane material achieve elevated isolation values as opposed to other mounts that use rubber or cork, or a combination of both. These antivibration mounts are manufactured in two special mixes of Sylomer® to adapt better to the load of each application.

A great variety of fixing metal armors and elements facilitate the installation and to adapt better to each type of job. Their rugged metal parts can withstand tensile stresses from 650Kg to 1000Kg. They are supplied with an anticorrosive treatment that can withstand the toughest environments.










DRAWINGS




DIMENSIONS

Туре	SUMMARY		Weight (kg)	Code
Akustik Rapid + Sylomer®30 Type A	Metal armor of the Akustik rapid secured to the ceiling by an M6 screw.	30	0,165	23507
Akustik Rapid + Sylomer®30 Type B	Metal armor of the Akustik Safety secured to the ceiling by an M6 screw.	30	0,165	23515
Akustik Rapid + Sylomer®50 Type A	Metal armor of the Akustik rapid secured to the ceiling by an M6 screw.	50	0,165	23582



DRAWINGS





DIMENSIONS

Туре	SUMMARY	LOAD kg MAX	Weight (kg)	Code
Akustik Rapid + Sylomer®50 Type B	Metal armor of the Akustik Safety secured to the ceiling by an M6 screw.	50	0,165	23583
Akustik Rapid + Sylomer®75 Type A	Metal armor of the Akustik rapid secured to the ceiling by an M6 screw.	75	0,175	23523
Akustik Rapid + Sylomer®75 Type B	Metal armor of the Akustik Safety secured to the ceiling by an M6 screw.	75	0,175	23531



Elastical properties





In order to adapt its products to the state of the art, AMC S.A. reserves the right to modify the conception and manufacture of the materials presented in this catalogue without prior notice.



OPERATION AND ASSEMBLY



1 .- Fix threaded wall plugs to the ceiling 2 .- Screw studbolts into the threaded wall plugs 3 .- Attach the acoustic hangers to the end of the studbolt 4 .- Level the hangers using a laser alignment tool 5 .- Fix the profiles to the acoustic hangers 6 .- Profiles fixedin position 7 .- Lower the safety flanges into position 8 .- Install supplementary fixings (optional) to provide additional safety feature 9 .- Acoustic hangers and profiles fixed 10 .- Place transverse profiles in position 11 .- Fix transverse profiles 12 .- Position plasterboards in place 13.- Plasterboards fixed. 14.- Plasterboards fixed. MIN/MAX Distances (Type A) MIN/MAX Distances (Type B)